

# BEDNET<sup>®</sup> ORIGINAL MINI

BN-0426, BN-0427

## INSTRUCTIONS

1. Unpack Bednet<sup>®</sup> from packaging.
2. Spread Bednet<sup>®</sup> over cargo with label facing up.
3. Connect the hooks to the desired anchor points in each corner of the cargo area. Make sure the rubber Bednet<sup>®</sup> label is facing up.
4. Pull straps taught, making sure the net stays centered over the load. There should be tension in the integrated straps.
5. Roll up excess strap and secure to hook end with hook and loop closures.

**For securing loads:** Repeat above draping Bednet<sup>®</sup> over load pulling all four adjust straps tight to secure cargo.

## WARNING

The attachment of this product is critical and beyond the control of Bednet<sup>®</sup>. Bednet<sup>®</sup> is NOT responsible for the attachment nor the installation. It neither guarantees, nor will it be liable for any damage resulting from the use of this product. Failure to use this product properly may cause cargo to shift or drop from the vehicle which may result in substantial property damage and or serious personal injury or death. Never use this product for lifting, towing or personal restraint. Do not use this product if hardware is defective, webbing is cut, frayed, exposed to extreme heat, burned, melted or abraded. This product was not designed to secure transportation of items or articles which are small enough to escape the restraint system. Do not exceed working load limit of 350 lbs. or minimum working load of anchor points to which this product is attached or product used to secure. Check your load and this product after first 10 miles and every 20 miles thereafter.

**READ COMPLETE OPERATING INSTRUCTIONS PRIOR TO USE.**

For technical information or other questions regarding our products, call toll free 1-866-423-3638 or visit us online at [www.thebednet.com](http://www.thebednet.com).