

BEDNET[®] UTILITY CARGO NET

BN-0272, BN-0275

INSTRUCTIONS

1. Drape the BEDNET[®] over your load with the label facing up and positioned at the rear of the truck bed.
2. Using tie-downs of your choice, secure the four corners of the BEDNET[®] by placing hook through the grommets and then securing the other hook to the anchor points in your truck bed and tighten.
3. Once all four corners of the BEDNET[®] are secured and tightened, use additional tie-downs in the available grommets if needed to further tighten the BEDNET[®] on your load.

Please note: Bednet[®] label must always be facing up.

WARNING

The attachment of this product is critical and beyond the control of BEDNET[®]. BEDNET[®] is NOT responsible for the attachment nor the installation. It neither guarantees, nor will it be liable for any damage resulting from the use of this product. Failure to use this product properly may cause cargo to shift or drop from the vehicle which may result in substantial property damage and or serious personal injury or death. Never use this product for lifting, towing or personal restraint. Do not use this product if hardware is defective, webbing is cut, frayed, exposed to extreme heat, burned, melted or abraded. This product was not designed to secure transportation of items or articles which are small enough to escape the restraint system. Do not exceed working load limit of 800 lbs. or minimum working load of anchor points to which this product is attached or product used to secure. Check your load and this product after first 10 miles and every 20 miles thereafter.

READ COMPLETE OPERATING INSTRUCTIONS PRIOR TO USE.

For technical information or other questions regarding our products, call toll free 1-866-423-3638 or visit us online at www.thebednet.com.